

FY90Q STICKER ADVISORY

WARNING:

DO NOT FOLLOW THE CONNECTIONS AS NOTED ON THE FY90Q STICKER:



THIS IS THE CORRECT PIN CONNECTION SEQUENCE:

The list of the pin Interface:

9	8	7	6	5	4	3	2	1	No.
Not used	ESC1 Output	ESC2 Output	ESC3 Output	ESC4 Output	GND	Power	Reset the gyro2	Reset the gyro1	A
X-mode	Power	Power	Power	Power	SW IN	RUD IN	THR IN	ELE IN	B
GND	GND	GND	GND	GND	GND	Power (to Receiver)	AIL IN	Not used	C

USE THE WIRE COLOUR TO TRACE THE CONNECTION TO YOUR RECEIVER:



END OF ADVISORY

www.fyetechn.com